

Installation Guide



1. FIT EAVES BEAM

APPLY A SEALANT TO BASE OF EAVES BEAM AND FIX EAVES BEAM ON TOP OF FRONT WINDOW. REF A

70mm W WINDOW FRAMES - FRONT COVER OF EAVES BEAM SHOULD TOUCH WINDOW FRAMES AS SHOWN. REF B

LESS THAN 70mm THICKNESS WINDOWS YOU SHOULD FIT EAVES BEAM WITH NO MORE THAN 10mm OF LIP SHOWING INSIDE AS RINGED ON REF C




MAKE SURE YOU USE ENOUGH FIXINGS TO ATTACH YOUR ROOF SECURELY TO THE FRAMES



7. FIT RAFTER END PLATES

WITH THE SUPPLIED SCREWS FIX THE GLAZING BAR END PLATES

USE THE CORRECT HOLE ON THE END PLATE TO SUIT THE THICKNESS OF GLAZING SO THAT THE END PLATE COVERS THE GLAZING BAR TOP CAP. REF J




5. GLAZE PANELS

EACH PANEL HAS A JOB LABEL, ON THIS LABEL IT GIVES A PANELS NUMBER. PANELS ARE NUMBERED FROM LEFT TO RIGHT FACING ROOF, LOCATE THE 1ST PANEL & LAY PANEL IN BETWEEN GLAZING BARS WITH THE PVC END DRIP OF THE SHEET JUST LIPING OVER THE FRONT OF THE GLAZING BAR.

IMPORTANT - 1st FIT WALL PLATE TO P CAP

BEFORE YOU FIT THE GLAZING BAR TO P CAPS FIRST FIT THE WALL PLATE TO P CAP BY CLIPPING IT DOWN UNTIL THE RUBBER SEAL TOUCHES THE GLAZING PANELS ON THE ROOF



IMPORTANT. SPRAY LUBRICATION ON THE PANELS EITHER SIDE OF THE GLAZING BAR TO BE CLIPPED. THIS HELPS THE CAPS CLIP DOWN. STARTING AT THE BACK END OF THE ROOF GENTLY BUT FIRMLY PUSH OR TAP DOWN THE CAP UNTIL THE GLAZING BAR TOUCHES THE PANEL, WORKING YOUR WAY DOWN TO THE FRONT.


TO P CAPS MUST BE LUBRICATED BEFORE BEING CLIPPED DOWN

2. FIT WALL PLATE

FIT THE WALL PLATE TO THE BACK WALL OF THE HOUSE. REF D

MAKE SURE YOU USE ENOUGH FIXINGS TO ATTACH YOUR ROOF SECURELY TO THE BACK WALL

CHECK YOUR ROOF CONFIRMATION PLAN FOR THE CORRECT HEIGHT TO FIX THE WALL PLATE. ALTERNATIVELY, USING ONE OF THE GLAZING BARS FROM THE KIT AS A GUIDE, LOOSELY FIX GLAZING BAR INTO THE FRONT EAVES BEAM WITH A SINGLE BOLT THEN RAISE OR LOWER THE WALLPLATE UNTIL YOU CAN PASS A BOLT THROUGH THE HOLES OF THE WALLPLATE AND GLAZING BAR THIS SHOWS THE WALL PLATE IS NOW AT THE CORRECT HEIGHT.



3. FIT GLAZING BARS



EACH BAR HAS 2 HOLES PUNCHED EACH END. ONE SET 20mm (FOR THE WALL PLATE) ANOTHER SET 110mm FROM THE END (FOR THE EAVES BEAM)

THE M6 X 20mm BOLTS ARE FOR THE WALL PLATE THE M6 X 30mm BOLTS ARE FOR THE EAVES BEAM

FIX THE GLAZING BARS TO THE ROOF USING M6 BOLTS SUPPLIED (ENSURE THAT THE RUBBER SEALING WASHERS ARE ON THE BOLTS BEFORE FITTING THEM) REF E


NOTES

THE TWO END BARS OF THE ROOF REQUIRE END ADAPTERS TO BE FITTED INTO ONE SIDE OF THE GLAZING BAR AS SHOWN IN REF F



4. CLIP EAVES INFILLS

CLIP IN THE EAVES INFILLS IN BETWEEN EACH GLAZING BAR. THIS SECTION COMES OVER SIZE AND WILL NEED TRIMMING TO SIZE AND GIVE A DRAUGHT SEAL TO THE GLAZING SHEETS. REF F



5. CLIP IN GUTTER BRACKETS

CLIP ON GUTTER BRACKETS BY HOOKING BRACKET ONTO EAVES BEAM AS SHOWN AND ROTATE DOWN UNTIL IT LOCKS INTO PLACE. REF H

